

Adjuvant Need based on sprayer volume

Adjuvant amount per spray tank (litres)

Adjuvant rate%	1000 litres	1500 litres	2000 litres	2500 litres
0.03%	0.25	0.38	0.50	0.63
0.05%	0.50	0.75	1.00	1.25
0.10%	1.00	1.50	2.00	2.50
0.13%	1.25	1.88	2.50	3.13
0.14%	1.40	2.10	2.80	3.50
0.20%	2.00	3.00	4.00	5.00
0.25%	2.50	3.75	5.00	6.25
0.50%	5.00	7.50	10.00	12.50
1.00%	10.00	15.00	20.00	25.00

Example.

For a 1500 litre sprayer using an adjuvant at 0.2% spray volume, you will require 3.0lt of adjuvant to be added to your 1500 litre sprayer

Adjuvant need based on litres per hectare of water sprayed

Amount of adjuvant per hectare (litres)

Adjuvant rate%	100 litres	150 litres	200 litres	250 litres
0.03%	0.025	0.380	0.050	0.063
0.05%	0.050	0.075	0.100	0.125
0.10%	0.100	0.150	0.200	0.250
0.13%	0.125	0.188	0.250	0.313
0.14%	0.140	0.210	0.280	0.350
0.20%	0.200	0.300	0.400	0.500
0.25%	0.250	0.375	0.500	0.625
0.50%	0.050	0.750	1.000	1.250
1.00%	1.000	1.500	2.000	2.500